

# JAX-V4

## SERVICE MANUAL



E Model

Ver 1.0 2003.09

- JAX-V4 is composed of the following models.  
As service manuals are issued for each component model, please refer to them.

### COMPONENT MODEL NAME

	JAX-V4
COMPACT DISC DECK RECEIVER	CX-JV4
SPEAKER SYSTEM	SX-JV4

### SPECIFICATIONS

Power requirements	110-120V/220-240 V AC (Switchable), 50 Hz/60 Hz
Power consumption	130 W
Power consumption in standby mode	With ECO mode on: 0.25 W With ECO mode off: 25 W
Dimensions (W x H x D)	280 x 330 x 392.5 mm
Weight	8.1 kg

### Supplied accessories

Remote commander (1)  
Batteries (2)  
Video connecting cord (1)  
FM antenna (1)  
AM antenna (1)

Specifications and external appearance are subject to change without notice.

### ACCESSORIES

<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
1-478-179-11	COMMANDER, STANDARD (RM-Z20011)	
1-501-374-92	ANTENNA, LOOP (AM)	
1-751-619-13	CORD, CONNECTION (VIDEO CONNECTING CORD)	
1-793-184-23	CONNECTOR (F TYPE ADAPTOR) (FM)	
4-245-998-01	COVER, BATTERY (for RM-Z20011)	
4-249-034-12	MANUAL, INSTRUCTION (ENGLISH, FRENCH)	
4-249-034-32	MANUAL, INSTRUCTION (ARABIC, PERSIAN)	

## MINI Hi-Fi COMPONENT SYSTEM

9-961-181-01 **Sony Corporation**  
2003I05-1 **Home Audio Company**  
© 2003.09 **Published by Sony Engineering Corporation**

