

# XR-EM400

## SERVICE MANUAL



*AEP Model  
UK Model*

**Ver 1.0 2003.07**

- XR-EM400 is composed of following models.  
As for the service manual, it is issued for each component model, then, please refer to them.

### COMPONENT MODEL NAME

	XR-EM400
COMPACT DISK DECK RECEIVER SYSTEM	CX-LEM400
SPEAKER SYSTEM	SX-LEM400

### PARTS LIST

<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
ACCESSORIES *****		
1-478-163-11	COMMANDER,STANDARD (RM-Z20027)	
1-754-102-31	ANTENNA, ROOP (AM)	
1-754-243-11	ANTENNA (FM)	
△ 1-770-019-51	ADAPTOR, CONVERSION PLUG (UK)	
1-793-184-23	CONNECTOR (F TYPE ADAPTOR)	
4-250-367-11	MANUAL, INSTRUCTION (ENGLISH, SPANISH, FRENCH, GERMAN, ITALIAN, RUSSIAN, CZECH, HUNGARIAN,POLISH)(AEP)	
4-250-367-21	MANUAL, INSTRUCTION (ENGLISH)(UK)	
4-249-131-01	COVER BATTERY (FOR RM-Z20027)	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

## MICRO HI-FI COMPONENT SYSTEM

9-961-018-01  
2003G16-1  
© 2003.07

**Sony Corporation**  
Home Audio Company  
Published by Sony Engineering Corporation

