

XR-MN5

SERVICE MANUAL



Ver 1.1 2003.06

- XR-MN5 are composed of following models.
As for the service manual, it is issued for each component model, then, please refer to them.

US Model
Canadian Model
AEP Model
UK Model
E Model
Australian Model

COMPONENT MODEL NAME

	XR-MN5
COMPACT DISK DECK RECEIVER SYSTEM	CX-LMN5
SPEAKER SYSTEM	SX-LMN5

- Abbreviation
AUS : Australian model. TW : Taiwan model.
CND : Canadian model. KR : Korean model.
SP : Singapore model. TH : Thai model.

SPECIFICATIONS

Power requirements	220 V AC, 50/60 Hz (KR) 110-240 V AC, 50/60 Hz (TH) 220-240 V AC, 50/60 Hz (SP) 240 V AC, 50/60 Hz (AUS) 230 V AC, 50/60 Hz (AEP,UK) 120 V AC, 60 Hz (US,CND,TW) 120V/220V/230-240 V AC, 50/60 Hz (E)
Power consumption	85W (EXCEPT US,CND) 80W (US,CND)
Power consumption in stanby mode	with ECO mode on: 0.26 W (EXCEPT E) 0.35W (E) 0.25 W (US,CND) 0.26 W (AEP,UK) 0.26 W(TH,KR) 0.35 W(OTHER) with ECO mode off: 15 W (EXCEPT E) 18 W(E) 16 W (US,CND) 15 W (AEP,UK) 18 W (TH,KR) 18 W (OTHER)
Dimensions (w/h/d)	Approx. 190 × 277 × 353 mm.
Mass	Approx. 6.8 kg
Supplied accessories	FM antenna (1) AM antenna (1) Speaker cords (2) Remote commander (1) Batteries (2)

Specification and external appearance are subject to change without notice.

PARTS LIST

Part No.	Description	Remark
	ACCESSORIES *****	
1-477-915-11	COMMANDER, STANDARD (RM-Z20019)	
1-501-374-92	ANTENNA, LOOP (AM)	
△ 1-569-008-12	ADAPTOR, CONVERSION 2P (E,SP,TW)	
1-754-243-11	ANTENNA (FM)(US,CND)	
△ 1-770-019-15	ADAPTOR, CONVERSION PLUG (UK)	
1-793-184-22	CONNECTOR (F TYPE ADAPTOR)(FM)(EXCEPT US,CND)	
1-827-378-11	CORD (FOR SPEAKER)	
4-245-958-01	FOOT (FOR SPEAKER)	
4-246-022-01	MANUAL, INSTRUCTION (ENGLISH,SPANISH)(US)	
4-246-022-11	MANUAL, INSTRUCTION (ENGLISH,FRENCH,POLISH, GERMAN,DUTCH,ITALIAN,SWEDISH)(AEP)	
4-246-022-21	MANUAL, INSTRUCTION (ENGLISH)(UK)	
4-246-022-31	MANUAL, INSTRUCTION (ENGLISH,SPANISH)(E)	
4-246-022-41	MANUAL, INSTRUCTION (ENGLISH,FRENCH)(CND)	
4-246-022-51	MANUAL, INSTRUCTION (ENGLISH,THAI)(TH)	
4-246-022-61	MANUAL, INSTRUCTION (ENGLISH,FRENCH,SPANISH,CHINESE)(SP)	
4-246-022-71	MANUAL, INSTRUCTION (KOREAN)(KR)	
4-246-022-91	MANUAL, INSTRUCTION (ENGLISH,CHINESE)(TW)	
4-249-131-01	COVER, BATTERY (FOR RM-Z20019)	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

MICRO HI-FI COMPONENT SYSTEM

