

# DAV-SA30

## SERVICE MANUAL



AEP Model  
UK Model  
E Model  
Australian Model

Ver 1.0 2003.05

- DAV-SA30 are composed of following models. As service manuals are issued for each component model, please refer to them.

### Abbreviation

AU/S : Australian model. KR : Korean model.  
 EA : Saudi Arabia model. SP : Singapore model.  
 HK : Hong Kong model. TW : Taiwan model.

### COMPONENT MODEL NAME

	DAV-SA30
SACD/DVD RECEIVER	HCD-SA30
PACKAGE SPEAKER	SS-WT3
FRONT/CENTER/ REAR SPEAKER	SS-TS3
SUB WOOFER	SS-WS3

### SPECIFICATIONS

#### General

Power requirements  
 Australia and Asian models: 230 ~ 240 V AC, 50/60 Hz  
 Saudi Arabian model: 120 ~ 127 V, 320 V or 230 ~ 240 V AC, 50/60 Hz  
 Adjustable with voltage selector

Voltage selector models:  
 120 V, 220 V or 230 ~ 240 V AC 50/60 Hz  
 Adjustable with voltage selector

Power consumption  
 Other models: 90 W

Dimensions (approx.)  
 355 × 75 × 360 mm  
 (14 × 3 1/4 × 14 1/4 inches) (w/ h/d) incl. projecting parts

Mass (approx.)  
 5.9 kg (13 lb 1 oz)

Operating temperature  
 5°C to 35°C (41°F to 95°F)

Operating humidity  
 5 % to 90 %

Supplied accessories  
 Speakers (5)  
 Subwoofer (1)  
 AM loop aerial (1)  
 FM wire aerial (1)  
 Speaker cords (5m × 4, 1.5m × 2)  
 (17ft. × 4, 50ft. × 2)  
 Video cord (1)  
 Remote Commander (remote) (1)  
 R6 (size AA) batteries (2)  
 Foot pads (15)  
 Speakers-connection and Installation (card) (1)

### PARTS LIST

Part No.	Description	Remark
ACCESSORIES *****		
1-477-703-11	COMMANDER, STANDARD (RM-SP400)	
△ 1-569-008-12	ADAPTOR, CONVERSION 2P (E, SP, KR, EA)	
1-754-149-11	LOOP ANT (AM)	
1-754-243-11	ANTENNA (FM)	
1-769-108-11	CORD, CONNECTION (VIDEO CORD)(E, SP, HK, TW, KR, EA, AUS)	
1-824-622-11	CORD (WITH CONNECTOR)(RED)	
1-824-622-21	CORD (WITH CONNECTOR)(PURPLE)	
1-824-622-31	CORD (WITH CONNECTOR)(WHITE)	
1-824-622-41	CORD (WITH CONNECTOR)(GRAY)	
1-824-622-51	CORD (WITH CONNECTOR)(BLUE)	
1-824-622-61	CORD (WITH CONNECTOR)(GREEN)	
4-236-887-02	CUSHION (SPK)(E, SP, HK, TW, KR, EA, AUS)	
4-240-873-02	COVER, BATTERY (FOR RM-SP400)	
4-243-457-01	RUBBER (SPEAKER)(AEP, UK)	
4-244-992-11	MANUAL, INSTRUCTION (ENGLISH)(E, SP, HK, TW, EA, AUS)	
4-244-992-21	MANUAL, INSTRUCTION (FRENCH)(E, SP, EA)	
4-244-992-31	MANUAL, INSTRUCTION (SPANISH)(E, SP)	
4-244-992-41	MANUAL, INSTRUCTION (ARABIC)(EA)	
4-244-992-51	MANUAL, INSTRUCTION (TRADITIONAL CHINESE)(SP, HK, TW)	
4-244-996-11	MANUAL, INSTRUCTION (ENGLISH)(AEP, UK)	
4-244-996-21	MANUAL, INSTRUCTION (FRENCH, SPANISH)(AEP)	
4-244-996-31	MANUAL, INSTRUCTION (GERMAN, DUTCH, ITALIAN)(AEP)	
4-244-996-41	MANUAL, INSTRUCTION (SWEDISH, POLISH)(AEP)	
4-244-992-61	MANUAL, INSTRUCTION (KOREAN)(KR)	
4-244-994-11	MANUAL, INSTRUCTION (ENGLISH)(AEP, UK, RU)	
4-244-994-21	MANUAL, INSTRUCTION (FRENCH, SPANISH)(AEP)	
4-244-994-31	MANUAL, INSTRUCTION (GERMAN, DUTCH, ITALIAN)(AEP)	
4-244-994-41	MANUAL, INSTRUCTION (SWEDISH, POLISH)(AEP)	
4-244-994-51	MANUAL, INSTRUCTION (DANISH, FINNISH)(AEP)	
4-244-994-61	MANUAL, INSTRUCTION (PORTUGUESE)(AEP)	
4-244-994-71	MANUAL, INSTRUCTION (GREEK)(AEP)	
4-244-996-51	MANUAL, INSTRUCTION (RUSSIAN)(RU)	

The components identified by mark △, or dotted line with mark △, are critical for safety. Replace only with part number specified.

## COMPACT AV SYSTEM

# SONY®

9-877-176-01 Sony Corporation  
 2003E16-1 Home Audio Company  
 © 2003.05 Published by Sony Engineering Corporation